

€ Surface thermometer and thermostat

Devices designed to display, control and regulate cooling generators (manual or automatic programmable defrosting by stopping the compressor) or heating generators.

1- Versions and References

MODEL	FUNCTION	RELAY	POWER SUPPLY, 50/60HZ
AKO-14602	Thermometer	-	230 V~ ±10%
AKO-14610	Thermostat	16 (4) A, 250 V cos φ=1, SPST	230 V~ ±10%
AKO-14612	Thermostat	16 (4) A, 250 V cos φ=1, SPST	120 V~ + 8%-12%

2- Technical data

Temperature range according to type of sensor configured:

- NTC -50.0 °C to 99.9 °C (-58.0 °F to 211 °F)
- PTC -50.0 °C to 150 °C (-58.0 °F to 302 °F)

Resolution, Set Point and differential: ... 0,1 or 1 °C/°F configurable by parameter P7
Input for probe:

- NTC **AKO-149XX**
- PTC **AKO-1558XX**

Thermometric accuracy: ± 1 °C
Probe tolerance at 25 °C:

- NTC ± 0,4 °C
- PTC ± 1.25 °C

Maximum input power: 3 VA
Working ambient temperature: 5 °C to 50 °C
Storage ambient temperature: -30 °C to 70 °C
Control device classification:

Independent mounting, with characteristic of automatic operation Type 1.B action, to be used in a clean situation, logical medium (software) class A and continuous operation. Degree of contamination 2 on UNE-EN 60730-1

Double insulation between the power supply, the secondary circuit and the relay output. Allocated pulse temperature: 2500 V
Pressure ball test temperature:

- Accessible parts 75 °C
- Parts that position active elements: 125 °C


Voltage and current declared by the EMC tests: **AKO-14602**: 207 V, 15 mA
..... **AKO-14610**: 207 V, 17 mA
..... **AKO-14612**: 105 V, 30 mA
Current of radio jamming suppression test: 270 mA

3- Installation

The controller should be installed in a place protected from vibrations, water and corrosive gases, and where ambient temperature does not surpass the value specified in the technical data.


In order to give a correct reading, the probe should be installed in a place without heat influences other than the temperature that is to be measured or controlled.

3.1 Fastening:



3.2 Connection:

The probe and its lead should **NEVER** be installed in ducting along with power, control or power supply wiring. The power supply circuit should be connected with a minimum 2 A, 230 V, switch located close to the unit. Power supply cables should be H05VV-F 2x0,5 mm² or H05V-K 2x0,5 mm²



Section of connecting wires for relays contacts should be 2,5 mm².

4- Front panel functions

LED Compressor ❄️

Permanent: Relay (compressor) energised if control operates in cold.

Flashing: Because of the temperature detected by Sensor, the COOL relay should be energised, but is no due to a programmed parameter.

LED Heat ⚡️

Permanent: Relay energised if control operates in heat.

Flashing: Because of the temperature detected by Sensor, the relay should be energised, but is no due to a programmed parameter.

LED Defrost ❄️ (Def)

Permanent: Indicates defrost in operation
LED °C

Permanent : Degrees °C indicator.

Flashing : Programming phase.


LED °F

Permanent : Degrees °F indicator.

Flashing : Programming phase.

UP key ⬆️

- In programming, it makes the displayed value increase.
- When pressed for at least 5 seconds,



a manual defrost is started with programmed duration.

DOWN key ⬇️

- In programming, it makes the displayed value reduce

RIGHT key ➡️

- In programming, it makes the level value increase.

LEFT key ⬅️

- Exit programming level.

SET key SET

- In programming, accept the programmed new value.
- When pressed for at least 5 seconds, the SP Set Point temperature is displayed.

5- Adjustment and configuration

It should only be programmed or modified by personnel who are fully conversant with the equipment operation and possibilities.

5.1 Set Point temperature

The factory SET POINT default value is 0.0 °C.

- Press **SET** key for at least 5 seconds to DISPLAY SET POINT. It displays the CURRENT SET POINT value and LED °C or °F starts flashing.
- Press **UP** or **DOWN** keys to CHANGE SET POINT into the required value.
- Press **SET** key to ACCEPT THE NEW SET POINT. The display returns to the CURRENT TEMPERATURE display status and LED °C or °F stops flashing.
- Press the **LEFT** key to exit the temperature set point without modifying the value. When **PA** is displayed, PASSWORD programmed in **L5** parameter of **tid** menu should be entered to access the CURRENT SET POINT.
- Press **RIGHT** key. 0 will be displayed to ENTER PASSWORD.
- Press **UP** or **DOWN** keys to CHANGE NUMBER and DISPLAY PASSWORD programmed.
- Press **SET** key to ACCEPT PASSWORD. The CURRENT SET POINT value will be displayed and it can be already modified.

